



NOTES:

1. LOCATE HANDHOLE AS DIRECTED BY C.O.B. ELECTRIC UTILITY.
2. INSTALL A MINIMUM 8" OF $\frac{3}{4}$ " CRUSHED ROCK UNDER HANDHOLE.

REF: J&R CONCRETE P-E6B



Proud History
Prosperous Tomorrow

REVISED: 02/04/2013

APPROVED: *[Signature]* 2-4-13

STANDARD DRAWINGS

POLYMER CONCRETE HANDHOLE,
17"x30"

SD

600-41